


Fabric Banner Stand assembly Instructions — STANDARD —

FABRIC

240g Tension Fabric
280g Blockout Fabric


DISPLAY SIZE

2FT、2.5FT、2.6FT、2.8FT
3FT、4FT、5FT




01

Put the tubes and plate in order.




02

Screw the tubes with matching numbers to the base.



03

Lengthen the tubes by connecting with the other tubes with the same number together. Make sure the thumb buttons slide into places.



04

Then a U shaped frame is completed.



05

Put on the fabric banner from the top to the bottom, To fully and snugly fit the frame, the fabric may be a little tight, so please pull it slowly.



06

Set the fabric banner upright, and start to display.